

SmallRig



4" Suction Cup Camera Support

User Manual

In order to ensure user's safety and prevent the product damages caused by any improper use, please carefully read the "Warnings" below and properly keep this User Manual for future reference.

Foreword

Thank you for purchasing SmallRig products.

Warnings

1. Please read this User Manual carefully.
2. Service Conditions: Suitable for dry, smooth, and clean surfaces Do not mount onto coated surface, marble, old tiles, porous wallpaper, mud walls, unpainted wooden wall, frosted glass, or other rough, and breathable surfaces.
3. Suitable Temperature: -20°F ~ 140°F.
4. Please follow the instructions correctly, there is no after-service while having damage to the product caused by abnormal conditions.
5. This product is not dustproof and waterproof, please do not use it in water.
6. Protect the product from falling to the ground or strong impact.
7. Do not place the product near combustible or corrosive solutions.
8. Do not disassemble the product by yourself to avoid malfunction due to improper operation.




01 Overview of the components.



02 Remove the dust cover of the suction cup and check the bottom of the suction cup before use, ensuring it is clean, intact, and undamaged.



03 Identify suitable surfaces that are dry, level, smooth, and sturdy. Wipe the suction surface clean before use to ensure dryness and smoothness. Press the suction cup with one hand and push the air pump inward with the other hand.




04 Identify surfaces such as natural marble surfaces, old tile surfaces, breathable wallpaper surfaces, diatomaceous earth wall surfaces, unpainted wooden surfaces, frosted glass surfaces, and other rough or breathable material surfaces that cannot be used.



05 When the white marking line on the air pump is only partially retracted, it indicates that the suction is incomplete. Please continue pressing the air pump until it is tightly locked in place.



06 Keep pushing the air pump inward until it can no longer be pushed in.



07 The white marking line becomes invisible, indicating that the air pump has reached the shortest length (compared to Figure. 5) and is ready for use.



08 When disassembling, simultaneously pull up on the handle until the suction cup unlocks.



09 Mount the dust cover and store the suction cup for future use.

Service & Warranty

Please keep your original receipt and guarantee card. Be sure the dealer has written on it the date of purchase and SN of the product. These are required for warranty service.

After-sale Warranty Terms

SmallRig products are entitled to warranty services as of the date of payment.

- Electronic products (except V mount battery): 1-year warranty.
- V mount battery: 2-year warranty.
- Non-electronic products: 2-year warranty.

Note: In case of any conflict between our warranty period policy and applicable laws and regulations of the country / region where the products are sold, the latter shall prevail.

This Warranty Does Not Cover

1. If users fail to adhere to the "Operating Instruction" or any "Warnings" stated in the user manual, resulting in a quality failure, it falls outside the scope of warranty coverage.
2. The product identification or SN label is removed or defaced in any way.
3. Product damage caused by problems not attributable to the quality of the products such as improper use of the products.
4. Product damage caused by unauthorized modification, disassembly, repair and other acts.
5. Product damage caused by fires, floods, lightning and other force majeure factors.

Warranty Mode

- For the products within the scope of warranty, SmallRig will repair or replace them on the basis of specific failures; the repaired / replaced products / parts are entitled to the remaining part of the original warranty period.

Contact Information

- You're advised to contact the online customer service personnel of corresponding shopping platform and submit a repair service application.
- You may also apply for repair service through SmallRig's service email.

Service Email: support@smallrig.com

Guarantee Card

ID No.	
Item Name	
Purchase Date	
User Name	
Mobile	
Address	
Receipt	

EC	REP	Prolinx GmbH Brehmstr.56,40239 Duesseldorf Germany eu@eulinx.eu
UK	REP	Prolinx Global LTD 27 Old Gloucester Street London,WC1N3AX, UK eu@eulinx.eu

Manufacturer: Shenzhen Leqi Innovation Co., Ltd.

Add: Rooms 103, 501 and 601, Building 5, Fenghe Industrial Park, Nos. 1301-50
Guanguang Road, Longhua District, Shenzhen, Guangdong, China.

Consignor: Shenzhen LC Co., Ltd

Add: Rooms 602, Building 5, Fenghe Industrial Park, No. 1301-50 Guanguang Road,
Xinlan Community, Guanlan Street, Longhua District, Shenzhen, Guangdong, China.

CE RoHS



WE ARE HERE FOR YOU
服务与支持

ETICHETTATURA AMBIENTALE
ENVIRONMENTAL LABELING

Made in China

SmallRig



4"车载吸盘支撑件

用户手册

为了保障使用者的安全以及防止不当使用导致产品损坏，请在使用前仔细阅读本手册的“重要提示”，并妥善保管好手册资料，以备随时查阅

前言

感谢您购买SmallRig产品。

重要提示

1. 请认真阅读本用户手册
2. 吸盘支架适用于干燥、平整、光洁的表面，不适用：涂料表面、天然大理石表面、老旧瓷砖面、透气墙纸、硅藻泥墙面、未喷漆的木头表面、毛玻璃表面、其他粗糙或透气的材质表面
3. 适用温度为 $-20^{\circ}\text{C} \sim 60^{\circ}\text{C}$
4. 请遵循说明操作，非正常条件下造成的产品损伤不予售后
5. 请勿在水中使用，本产品不具备防尘、防水功能
6. 请勿让产品掉落到地面或强烈冲击
7. 请勿将产品放置在可燃或腐蚀性溶液附近
8. 请勿擅自拆卸本产品，避免因操作不当造成产品故障



01 产品平铺图




02 使用前取下吸盘防尘罩，并检查吸盘底部干净、完整无破损



03 适用于干燥、平整、光洁、坚固的表面。使用前可擦拭吸附面，保证干燥平整。一只手按压吸盘，另外一只手向内推动抽气泵




04 涂料表面、天然大理石表面、老旧瓷砖面、透气墙纸、硅藻泥墙面、未喷漆的木头表面、毛玻璃表面、其他粗糙或透气的材质表面不能使用



05 标识抽气泵白色警示线刚刚收进去时，依然处于未完全吸附状态，仍需要继续按压抽气泵使之锁紧



06 持续向内推抽气泵，直到不能再推为止



07 白色警示线完全推进，气泵已经达到最短状态（对比图5），判定达到可用状态



08 拆卸时，同时向上拉住抠手位，直到吸盘解锁



09 盖好吸盘防尘罩，收纳以备下次使用

保修条款

请保留您的原始购买单据及保修卡,同时包含您的购买日期、产品序列号等,这些资料质保服务时均需要提供。

售后质保条款

SmallRig产品自下单付款之日起享有质保服务。

- 电子产品(除V口电池): 1年质保。
- V口电池: 2年质保。
- 非电子产品: 2年质保。

注:若销售地国家或地区的适用法律法规有冲突的,以销售地国家或地区有关质保期的法律法规为准。

质保无效说明

1. 当用户违反操作指引或用户手册中“重要提示”任何一条导致的质量失效,不在质保范围内。
2. 产品序列号标识已经被撕毁或无法辨识,不在质保范围。
3. 产品使用不当等非产品本身质量问题,而造成的产品损坏,不在质保范围。
4. 非官方指导的私自改装、拆解、维修等行为而造成的损坏,不在质保范围。
5. 因火灾、水灾、雷击等不可抗力造成的产品损坏,不在质保范围。

维修方式

· 属于质保范围的,SmallRig 根据产品具体的故障对产品进行维修或更换; 维修后的产品 / 部件享受原有保修期的剩余时长。

联系方式

- 建议您优先前往相应购买平台联系在线客服,提出产品维修申请。
- 您也可以通过 SmallRig 服务邮箱申请维修服务。

服务邮箱: support@smallrig.com

保修卡

ID编号	
产品名称	
购买日期	
用户姓名	
用户电话	
用户地址	
购买单据	

执行标准: GB/T 26572-2011

制造商: 深圳市乐其创新股份有限公司

地址: 中国广东省深圳市龙华区观澜街道新澜社区观光路 1301-50 号丰和工业
园厂房 5 栋 103、501、601

委托商: 深圳市乐长科技有限公司

地址: 中国广东省深圳市龙华区观澜街道新澜社区观光路 1301-50 号丰和工业
园厂房 5 栋 602

CE RoHS



LQ-P1172-18

中国制造