

**SmallRig**

**D-Tap to NP-FZ100  
Dummy Battery Power Cable**

User Manual

## Foreword

Thank you for purchasing SmallRig products.

## Warnings

- Please read this User Manual Carefully before using the product.
- Keep the User Manual properly. If other users want to use this product, give this User Manual with the product.
- Note all the warnings and follow all the instructions provided in this user manual.
- Do not disassemble the product. If the product is deformed or gets wet, immediately stop all use.
- Avoid dropping the product. Do not use it in excessive temperature or short circuit situation.
- Keep out of reach of children.



Do not disassemble the product or change its battery.  
If you have any questions, please contact the seller to apply after-sales service.

## Intended Use

- Please read this User Manual carefully, especially the "Warnings".
- Please use or store the product in the environment mentioned herein.
- It will be regarded as an improper use when the users are not correctly follow the User Manual or use the product under the specific working condition.

## In the Box

D-Tap to NP-FZ100 Dummy Battery Power Cable	× 1
User Manual	× 1

## Specifications

Items	Parameters
Output Maximum Voltage	8.4V
Output Minimum Voltage	8.0V
D-Tap Input Voltage	9.6 - 20V
D-Tap Input Current	2A (Min)
Output Current	2A (Max) Continuous Output Current

Output Protection Current	3.8 ~ 4.9A
Operating Temperature	0°C ~ 45°C
Storage Temperature	- 20°C ~ + 60°C
Battery Case Material	ABS
Input Specifications	Male D-Tap connector, spring wire stretching to 2m ± 50mm

\* The data are measured by SmallRig Lab but may vary based on specific circumstances.

## How to use

1. Connect the dummy battery and the power.
2. Insert the powered dummy battery into the camera battery compartment correctly.
3. Close the battery compartment cover.